

Base Components

Closed Base Front:

- Snaps in place
- Fits flush with floor regardless of leveling adjustments
- 3' & 4' Fronts have an electrical knockout
- **For pricing see section 100, pg 70**

EXAMPLE PART NO.

CBF | 4 | 06

CBF = Closed Base Front

4 = Section Width: 2', 30", 3', 4'

06 = Base Height: "06" or "LB" Low Base

STANDARD FINISH:

CHR

Closed Base Front



Open Base Front:

- Used in place of Closed Base Front
- When using Open Base Front, order CHR Base Brackets (when complete Section/End part numbers are ordered, this is done automatically)
- **For pricing see section 100, pg 70**

EXAMPLE PART NO.

OBF | 4 | 06

OBF = Open Base Front

4 = Section Width: 2', 3', 4'

06 = Base Height: "06" or "LB" Low Base

STANDARD FINISH:

CHR

Open Base Front



Gap Filler:

- Steel Filler fills the gap between the Bottom Rail & floor on rear side of the Wall Shelving
- Compatible with either 06 Base or Low Base
- **For pricing see section 100, pg 70**

EXAMPLE PART NO.

GF | 4

GF = Gap Filler

4 = Width: 2', 30", 3', 4'

STANDARD FINISH:

CHR

Gap Filler

